

## Basic Operations

### **NOTE**

The explanation of functions described in this manual may differ from the actual operation, and the shapes of screens and buttons and the letters and characters displayed may also differ from the actual appearance. Additionally, depending on future software updates, the content may successively change without notice.

## Communication

By connecting your mobile device, such as a Smartphone, to Mazda Connect via Bluetooth<sup>®</sup>, you can perform hands-free calling and short message functions.

## Bluetooth® Hands-Free

When connecting a Bluetooth® device (mobile phone) to the vehicle's Bluetooth® unit via radio wave transmission, calls can be made or received.

### NOTE

- Park the vehicle in a safe place and perform pairing.
- The communication range of a Bluetooth® device is about 10 meters or shorter.
- Some Bluetooth® mobile devices are not compatible with the vehicle. Consult an Authorized Mazda Dealer, Mazda's call center or Web support center for information regarding Bluetooth® mobile device compatibility:
  - Website: <https://connect.mazda.com/en/>
  - U.S.A.  
Phone: 800-430-0153
  - Canada  
Phone: 800-430-0153
  - Mexico  
Center of Attention to Client (CAC)  
Phone: 01-800-01-MAZDA
  - Australia
  - New Zealand
  - Germany  
Phone: 0800 4263 738 (8:00—18:00 Central European Time)
  - Europe (Except Germany)  
Phone: 00800 4263 7383 (8:00—18:00 Central European Time)
  - Worldwide  
Phone: + 49 721 5099 8198 (8:00—18:00 Central European Time)

### Supported Bluetooth® standard (recommended)

**(MAZDA 3\*1, MAZDA CX-30\*1)**

Ver. 1.1/1.2/2.0 + EDR/2.1 + EDR/3.0 (conformity)

and devices that are compatible with Bluetooth® Ver. 3.0.


**(MAZDA 3\*1, MAZDA CX-30\*1, MAZDA MX-30, MAZDA CX-50, MAZDA CX-60, MAZDA CX-90)**

Ver. 1.1/1.2/2.0 + EDR/2.1 + EDR/3.0 (conformity)

and devices that are compatible with Bluetooth® Ver. 4.2.

\*1 Differs depending on the vehicle's period of manufacture.

## Component Parts



1. Center display
2. Volume adjustment button
3. Talk/pick-up button
4. Hang-up button
5. Microphone
6. Volume knob

The display and the shape of each switch may differ depending on the vehicle model.

### **Volume adjustment button**

Adjusts the voice guidance and conversation volume.

### **Talk/pick-up button**

Activates the voice recognition, skips the voice guidance.

In addition, when you press the button while on an incoming call, you can answer the call.

### **Hang-up button**

Ends the call or refuses an incoming call.

In addition, it ends the voice recognition operation.

## Volume knob

Adjusts the voice guidance and conversation volume the same as the volume adjustment button on the audio remote control switch. The volume increases by turning the dial clockwise, and decreases by turning it counterclockwise.

## Microphone (hands-free)

The microphone is used for inputting a voice command using voice recognition or when making a hands-free call.

### NOTE

The Bluetooth® Call Volume is independent of the Bluetooth® Audio volume, which is also independent of the AM/FM/USB audio volume. Ensure that the Bluetooth® device volume is set at a reasonable level, and then adjust the call volume using the Mazda Connect volume knob.


## ▼ Making a Call

For Mazda Connect, making calls is possible using any of the following six methods:

- Favorites
- Call history
- Phonebook downloaded from a Bluetooth® device (mobile phone)
- Dialing a telephone number
- “Redial”– Voice recognition command for making a call to the latest outgoing call history.

## Making a call from your Favorites


1. Select “Communication” on the home screen.




# Communication

---


2. Select "Favorites".



3. Select the contact information you want to make a call from the displayed Favorites list.




4. Select the telephone number and make the call.



## Making a call using the call history (outgoing call history, incoming call history)


### Operation using voice

Makes a call to the last person called (latest person on outgoing call history) from the mobile phone/vehicle.


1. Press the  on the audio remote control switch.
2. Say: "Redial"

## Center Display Operation


1. Select “Communication” on the home screen.



2. Select “Call History”.




3. Select the contact or telephone number you want to call from the displayed call history to make a call.



## Making a call using the contacts (phonebook)

### Operation using voice

Telephone calls can be made by saying the contact name in the downloaded phonebook.

1. Press the  on the audio remote control switch.
2. Say: “Call {Contact Name} at {Number Type}”  
For the {Contact Name}, say the name of the person registered in the phonebook. Depending on the registered content in a phonebook, calls can be made from “Home”, “Work”, “Mobile”, or “Other” telephone number types.

# Communication

---


3. Follow the voice guidance to make a call.

## NOTE


Make a call using the contact downloaded beforehand.  
Refer to Downloading a phonebook on page 2-104.

## Center Display Operation

1. Select “Communication” on the home screen.



2. Select “Contacts”.




3. Select the contact you want to call from the displayed contact list and make the call.





4. Select the phone number to make the call.




### Input the telephone number and make the call

#### **NOTE**

Practice this while parked until you are confident you can do it while driving in a non-taxing road situation. If you are not completely comfortable, make all calls from a safe parking position, and only start driving when you can devote your full attention to driving.


#### **Operation using voice**

You can make a call by saying the phone number.

1. Press the  on the audio remote control switch.
2. Say: "Dial {Phone Number}"
3. Follow the voice guidance to make a call.

#### **Center Display Operation**


1. Select "Communication" on the home screen.




# Communication


---

2. Select “Dial Pad”.





3. Input the telephone number using the dial pad.

4. Select  to make a call.



## NOTE

- Select  to delete the previous input number.
- Press and hold  to delete all input numbers.

## Automatic 911 dialing (U.S.A./Canada only)

If the vehicle is involved in a moderate to severe collision, a call is made automatically to 911 from the connected device. The “Emergency Assistance Call” setting must be on.

Refer to Communication Settings on page 2-112.



Though the system can be set to not call 911, doing so will defeat the purpose of the system. Mazda recommends that the Automatic 911 dialing system remain activated.

## NOTE

- **Automatic 911 dialing is a secondary function of the audio entertainment system. Therefore, the Automatic 911 dialing function does not assure that the call is always made to 911 after an accident occurs.**

- A Hands-free device must be paired and connected. The 911 operator can verify the vehicle's position information using the Hands-free device GPS if equipped.


The 911 operator can verify the vehicle's position information.


1. If the vehicle is involved in a moderate to severe collision, notification of the call to 911 is made via audio and screen display.  
To cancel the call, "Cancel" within 10 seconds.
2. If "Cancel" is not pressed within 10 seconds, the call is made to 911 automatically.


### ▼ Receiving a call

When the Incoming Call Notifications setting is turned on, the incoming call notification screen is displayed when receiving an incoming call.

Refer to Communication Settings on page 2-112.



When the conversation begins, press the  on the audio remote control switch on the steering wheel control switch, or select "Answer" on the screen.


To refuse a call, press the  on the audio remote control switch or select "Decline" on the screen.

### NOTE

When the Incoming Call Notifications setting is turned off, the incoming call notification screen is not displayed.

### ▼ Things you can do during a call

The following menu is displayed on the screen during a call. The displayed menu differs depending on the use conditions.



# Communication

Menu	Explanation
End	Ends the call.
Transfer to Mobile Device	Transfers a call from hands-free to a mobile phone. Communication between this unit and a Bluetooth® device is canceled, and an incoming call can be received by the device (mobile phone) as a standard call.
Transfer to Vehicle	Transfers a call from a device (mobile phone) to hands-free. Communication between devices (mobile phone) can be switched to Bluetooth® Hands-Free.
Mute	Mutes the microphone during a call.
Unmute	Cancel the mute for the microphone during a call.
Add Call	A call is made to another person during a call, and a 3-way call can be made. Select the contact from the following to make a call. <b>Call History</b> : The call history is displayed. <b>Contacts</b> : The phonebook is displayed. <b>Dial Pad</b> : The dial pad is displayed. Input the phone number. The function may not be available depending on the contractual content of the mobile device.
Dial Pad	<b>DTMF (Dual Tone Multi-Frequency Signal) Transmission</b> This function is used when transmitting DTMF via the dial pad. The receiver of a DTMF transmission is generally a home telephone answering machine or a company's automated guidance call center. Input the number using a dial pad.
Send Stored Tones	(When registering a phone number and DTMF data to a contact with whom you are currently calling.) Sends the DTMF data after the separator character (p or w) following the phone number.

## ▼ Downloading a phonebook

The phonebook data from the Bluetooth® device can be registered to the contacts on the unit using Bluetooth®.

### Automatic downloading


When the Contacts and Call History Sync setting is on, contacts and call history are automatically downloaded when connected to a Bluetooth® device.

Refer to Communication Settings on page 2-112.


### Manually downloading

When the Contacts and Call History Sync setting is off, download the phonebook using the following procedure.


1. Select “Communication” on the home screen.



2. Select “Contacts”.



3. Select “Update Contacts”.



**NOTE**

- The phonebook download uses the Bluetooth® PBAP profile.
- Up to 5,000 contacts can be registered.
- The phonebook, incoming/outgoing call history, and Favorite memories are exclusive to each paired Bluetooth® device to protect privacy.
- In downloading a phonebook from a Bluetooth® device, operations may be necessary on the Bluetooth® device side in addition to this unit. For details, refer to the Bluetooth® device’s owner’s manual.
- Contacts with no telephone number are not registered.

# Communication

---

## ▼ Registering contacts to Favorites


Up to 100 contacts can be registered. Registering the phone number saves time by you not having to search for the person you want to call in the phonebook.

### NOTE


The contacts need to be input (downloaded phonebook) beforehand. Refer to Downloading a phonebook on page 2-104.

### Registering to Favorites

1. Select “Communication” on the home screen.




2. Select “Contacts”.



3. Select the contact you want to register to Favorites from the displayed contact list.



4. Select “Add to Favorites”.



**NOTE**

If the lead-acid battery is disconnected, your Favorites list will not be deleted.

**Deleting Favorites/changing contact name of Favorites**

For deleting and changing contact names from your Favorites, refer to Favorites on page 1-17.

**▼ Receiving and replying to messages\***

SMS (Short Message Service) messages received by the connected Bluetooth® device can be downloaded, displayed on the center display, and read out loud. In addition, preset replies can also be made to calls and messages in the received messages.

**NOTE**

You may need to configure settings on your Bluetooth® device to utilize this function.

**Downloading messages**

You can download up to 50 recent messages from a connected Bluetooth® device and display them.

**Automatic downloading**

When the Message Sync setting is turned on, messages are automatically downloaded when the Bluetooth® device is connected. Refer to Communication Settings on page 2-112.

**Manually downloading**

If the Message Sync setting is turned off, messages can be downloaded using the following procedure.


# Communication

---

1. Select “Communication” on the home screen.



2. Select “Text Messages”.



3. When “Update List” is selected, the messages are downloaded from your Bluetooth® device.



## NOTE

- Attached data is not downloaded.
- Messages up to 160 characters can be downloaded.
- The messages that are stored are exclusive to each paired Bluetooth® device to protect privacy.
- The short message function uses the Bluetooth® MAP profile.
- To receive and reply to messages from your Bluetooth® device, operations and settings may be necessary on the Bluetooth® device side in addition to this unit. For details, refer to the Bluetooth® device’s owner’s manual.




**iPhone®**

**NOTE**


- When you connect an iPhone®, the following functions cannot be used.
  - Downloading past messages
  - Replying to messages

Do the following operation while connected after pairing is completed.

1. **(iPhone® operation)**  
Select the Settings menu → Bluetooth → Device “Mazda”.
2. **(iPhone® operation)**  
Turn on the Display notifications item.
3. **(Operation on this unit)**  
Turn off Bluetooth®.  
Refer to Connectivity Settings on page 2-140.




4. **(Operation on this unit)**  
Turn on Bluetooth® again and wait until the iPhone® automatically reconnects.



# Communication

## 5. (Operation on this unit)

After connecting the iPhone®, "Text Messages" can be used if it can be selected.




## Receiving messages

When the Text Message Notifications setting is on and your Bluetooth® device receives a message, the message notification will be displayed.

Refer to Communication Settings on page 2-112.

When "Read" is selected, messages are displayed.




The following menu is displayed on the message details screen. The displayed menu differs depending on the use conditions.


Menu	Explanation
Play	Reads out the currently displayed message.
Pause	Pauses the read out of a received message.
Previous	Displays the previous message.
Next	Displays the next message.
Reply	Only replies to the sender of the currently displayed message. Select the sentence on the displayed reply screen and select the sentence for sending from the preset message.
Call	Makes a call to the sender of the currently displayed message. If a phone number of a person who sent a message is unknown, a call cannot be made.

### Editing preset messages


1. Select "Communication" on the home screen.




2. Select "Communication Settings".



3. Select "Preset Text Messages".



4. Select the preset message you want to edit from the preset message list.





# Communication

---

5. When inputting the message you want to change and selecting ✓, the message is stored as a preset message.




## NOTE


- Select  to delete the previous input character. Press and hold it to delete all of the input characters.
- Slide the  to the left to return to the previous screen without storing the edit.

## ▼ Communication Settings

1. Select “Communication” on the home screen.



2. When “Communication Settings” is selected, the settings list is displayed. Select the menu you want to change from the settings list and change the setting.



Menu		Explanation
Add/Edit Device	Add Device	Performs the Bluetooth® device's connection settings. Refer to Connectivity Settings on page 2-140.
	Edit Device	You can change the connected Bluetooth® device. Refer to Connectivity Settings on page 2-140.
Device Notifications	Incoming Call Notifications	By changing the check status, you can set the notification on/off for when a call is received.
	Text Message Notifications*	By changing the check status, you can set the notification on/off for when a new message is received.
	Phone Sync Notification	By changing the check status, you can set the notification on/off for when the synchronization with a Bluetooth® device is completed.
Synchronization Settings	Message Sync*	When checked to turn the function on, SMS messages are downloaded automatically when your Bluetooth® device is connected.
	Contacts and Call History Sync	When checked to turn the function on, the phonebook and call history are downloaded automatically when your Bluetooth® device is connected.
Communication Audio Settings	Ringer* <sup>1</sup>	Changes the type of ring tone. <b>Vehicle:</b> Standard ring tone set on the vehicle <b>Phone:</b> Ring tone set on the Bluetooth® device
	Ringer Volume	Adjusts the ring tone volume.
	Message Notification Volume*	Adjusts the volume of the message received notification.
	Automatically Read Selected Messages*	When checked to turn the function on, received messages are read out automatically.
	Text Message Playback Vol.*	Adjusts the volume the message read out.
Other Settings	Display Contact Images	When checked to turn the function on, an image is displayed for the contact.
	Contacts Display Order	The display order of the contacts can be changed. <b>First, Last:</b> Displays in the order of first name, last name. <b>Last, First:</b> Displays in the order of last name, first name.
	Preset Text Messages*	Edits the preset message Refer to Receiving and replying to messages on page 2-107.
	Signature*	When checked to turn the function on, a signature is added when sending a message.
	Emergency Assistance Call*	Automatic 911 dialing can be set to enabled/disabled by changing the check status.

\*1 Depending on the connected Bluetooth® device, it may not be possible to select "Phone".